


**Ručný plazmový horák PHT-51 G/L**  
**/CUTi 90 a 120, CUTLINE 20G a 40G/**



## Spotrebné diely PHT-51 G/L

Poz.	Obj. číslo	Popis	Počet
00.00.00	.11.844.101.006	PHT-51 G/L 6m/120A plazm. ručný horák	1.00
00.00.00	.11.844.101.012	PHT-51 G/L 12m/120A plazm. ručný horák	1.00
01.00.00	.11.844.101.190	Hlava horáka PHT-51G/L, neosadená	1.00
02.04.01	.11.844.101.310	Katóda PHT-51 G/L	1.00
02.04.02	.11.844.104.310	Katóda, dlhá, PHT-51 G/L	1.00
02.05.00	.11.844.101.153	Rozvádzač plynu (VESPEL) PHT-51 G/L	1.00
02.07.01	.11.844.101.410	Dýza 1,0mm (20-50A) P2210	1.00
02.07.01	.11.844.101.412	Dýza 1,2mm (50-90A) P2212	1.00
02.07.01	.11.844.101.414	Dýza 1,4mm (90-120A) P2214	1.00
02.07.02	.11.844.104.412	Dýza, dlhá, 1.2 mm - P2412	1.00
02.07.02	.11.844.104.414	Dýza, dlhá, 1,4 (70A) P2414	1.00
02.07.03	.11.844.102.425	Dýza 2,5 P2325 drážkov.	1.00
02.08.00	.11.844.101.160	Ochranná hubica PHT-51 G/L	1.00
02.08.01	.11.844.101.162	Dištančná pružina PHT-51 G/L	1.00
02.08.02	.11.844.101.163	Fazetovacia korunka PHT-51 G/L	1.00
02.08.03	.11.844.101.164	Nasadzovacia hubica PHT-51 G/L	1.00
02.08.04	.11.844.101.165	Korunková dýza, dlhá, PHT-51 G/L	1.00
02.09.01	.11.844.101.161	Ochrana proti rozstreku	1.00
03.01.00	.11.844.101.250	Rukoväť, komplet, pre PHT-51 G/L	1.00
03.01.01	.11.844.001.255	Tlačidlo	1.00
08.00.01	.11.844.101.820	Viacúčelový kľúč	1.00
10.00.00	.11.844.101.890	Zariadenie na kruhové rezy PHT-51 G/L	1.00